

BODY TIPSES AND OPTIONS

MW

COMPLETE CODE

To obtain the complete code for an atomizer it is necessary to use the set-up code you have chosen from the performance table and complete it with the code for body and options as follows:

- Replace the first two letters in the set-up code (SU) with the code for standard body (MW).
- Add the code for the material you require.
- Add the code for the required options, if any, and the thread type code.

MWB 1520 X Y Z





MATERIALS


B1 = AISI 303 Stainless steel
B31 = AISI 316L Stainless steel
D1 = PVC
E6 = LUCITE® (PMMA)
T8 = Nickel plated brass

CONNECTION

G = BSP Female (EU)
N = NPT Female (US)

OPTIONS

<p>A </p> <p>B </p> <p>C </p> <p>D </p>	<p>BASIC BODY</p> <p>SHUT-OFF NEEDLE</p> <p>CLEANING NEEDLE</p> <p>CLEAN AND SHUT-OFF NEEDLE</p>
---	--



AA = Air Inlet (1/4" F)
 LI = Liquid inlet (1/4" F)